

G3S GLIDER-FINAL PRODUCTION RECORD

Schematic Rev		
SELECT ONE	X	1000M
		350M
CUSTOMER		Memorial
CUST. ORDER NO.		R123614-2
		SPECIAL

NOTE: FILL IN ALL REQ'D DATA, NO EMPTY SPACES, NO DITTOS.

ASSY / PART DESCRIPTION	DWG #	REV	SERIAL #
GLIDER ASSY (FILL IN) PN "GLD-XXX-NFC"	GLD-0107-D	NA	1
SHALLOW FRONT PUMP (SELECT ONE)	N/A	NA	NA
FWD SECTION ASSY (SELECT ONE)	ASSY 305685-1000	305685	B
ALTIMETER ASSY (SELECT ONE)	G-1414	G-1414	C
PAYLOAD BAY ASSY - Fill In	PLD-0105	NA	1
STACK-ON BAY - Fill In	A311627-NFC	A311627	1
AFT SECTION	A311317-NFC	A311317-NFC	1
AFT END CAP	ASSY 305654	305654	E
AFT TRAY	A311318-NFC	A311318-NFC	1
PRESSURE TRANSDUCER	ASSY G-1312	3002	C
RADOME FIN	ASSY 304376	304376	D
THRUSTER ASSY	ASSY 302409	302409	NA
Composite Hull, Fwd	ASSY G-1405-L	3135	K
Composite Hull, Aft	ASSY G-1405-L	3135	K
ASSY / PART DESCRIPTION	DWG #	VENDOR SERIAL #	
LITHIUM BATTERY, PITCH	Assy 305523	305523	132
LITHIUM BATTERY, AFT	Assy 305524	305524	115
ENERGY BAY BATTERY	NA	NA	NA
BATTERY, EMERGENCY	306318-NFC	306318	NA
FREEWAVE	ASSY 301784	301784	973-9655
ASSY / PART DESCRIPTION	VENDOR SERIAL #		
IRIDIUM SIM CARD (CUSTOMER SUPPLIED)	8988169234001174028		
ARGOS ID# (CUSTOMER SUPPLIED)	Dec. 224509 Hex. 32197D4		
ASSY / PART DESCRIPTION	VERSION #		
FIRMWARE, COTS TESTING	10.07-RC03		
HELIUM LEAK TEST			
<input checked="" type="checkbox"/> PASS <input type="checkbox"/> FAIL Initial: <u>AK</u> Date: <u>1/15/22</u>			
NOTES:	AD2CP	IP Address	192.168.0.240

Completion Date	<u>1/15/22</u>	Name (print)	<u>Adam Ritterbush</u>	Initials	<u>AK</u>
Inspection Date	<u>1/15/22</u>	Name (print)	<u>Josmin Gorman</u>	Initials	<u>JK</u>
Review Date	<u>1/28/22</u>	Name (print)	<u>Joe</u>	Initials	<u>JK</u>



This document and the information contained herein are proprietary to Teledyne Technologies, Inc. and may not be distributed outside of Teledyne Technologies, Inc., used, reproduced or disclosed without the prior, express, written consent of Teledyne Technologies, Inc.



Information included herein is controlled by the Export Administration Regulations (EAR) and may require an export license, license exception or other approval from the appropriate U.S. Government agency before being exported from the United States, reexported, transferred or retransferred to any non-U.S. person. Diversion contrary to U.S. law is prohibited.

GLIDER RELEASE RECORD

TO BE COMPLETED BEFORE FACTORY ACCEPTANCE TEST (FAT)
NOTE THESE STEPS ARE LISTED IN THEIR PREFERRED (NOT REQUIRED) ORDER

Step	Test description	Initials/Date	Pass/Fail
1	Glider Ballasting Procedure, Document #4095-GBP Spreadsheet Document #4095-GBPSH	KB 1/21/22	Pass
2	Confirm ballasting in tank (Only necessary if internal ballast was changed.)	N/A	N/A
3	Document #4095-GVI Glider Visual Inspection	KB 1/28/22	Pass
4	Document #4095-FSI or #4095-FSI-I Glider Final Seal Inspection	KB 1/21/22	Pass
5	Document #301750-HLT Helium Leak Test	KB 1/27/22	Pass
6	Verify Flight Testing is Complete	KB 1/28/22	Pass

FACTORY ACCEPTANCE TEST (FAT) WITH CUSTOMER (IF REQUIRED)

1	Document #4095-FCP or #4095-FCP-I Functional Checkout Procedure	KB 1/28/22	Pass
2	(Optional, as requested by customer) Document #4095-CICT Customer Iridium Communications Test	N/A	N/A
3	Install science sensor covers. For Aanderaa optodes, be sure to fill rubber cover with water.	KB 1/28/22	Pass

COMMENTS:

FINAL APPROVAL FOR PRODUCT SHIPPING

Customer Witness (if Applicable)

Date:

TWR:

Date: 1/28/22

QA/ Production Supervisor Review:

Date: 1/28/22



Ballasting The Slocum Glider (Spreadsheet)

Reference Ballasting Procedure 4095-GBP

1- Fill in all fields that are shaded in blue

2- Adjust weight by amount in yellow box to go from neutrally buoyant in tank to neutrally buoyant in target water

Glider Name:	Unit 970	
Ballasted by:	DS	
Date:	1/21/2022	
Glider Type:	G2 Deep (1000m)	

Add-ons (check box for each)	G1 Shallow Science Bay	1st	2nd
	G1 Deep/G2 Science Bay	1st	2nd
	G2 Extended Science/ Energy Bay (14.85")		
	DVL Bay (5.75")	1st	2nd
	ES Science/Energy Bay (15.75")		
	Mark III Aft End Cap		
	Rockland Scientific Microrider		
	SUNA Nitrate Sensor		
	Pond Wings		
	Pinger		
Insert Glider-specific Volume Adjustment Here	11.0245		
Base Glider Displacement:	46.02	Liters	
Total Glider Displacement:	67.76	Liters	

	Tank Water	Target Water	Weight Change
Temperature and	19.2877 °C	19.2877 °C	0.0000 grams
(Density or	0.0000 g/L °C	0.0000 g/L °C	
Conductivity or	4.8092 s/m	4.8092 s/m	
Salinity)	0.0000 pss	0.0000 pss	
Calculated/given Salinity	35.7506 pss	35.7506 pss	
Calculated/given Density	1025.5221 g/L °C	1025.5221 g/L °C	0.0000 grams
Total Weight Adjustment:			0.0000 grams

Drive Weight Material	
Configure 2 Drive Weights, Each Weighing (g)	

Battery Type:	Lithium	weight (kg)
Pitch Configuration	Lithium Pitch Pack	8.5222
Science/Energy Bay Configuration	N/A	NA
Aft Configuration	Lithium Aft Pack	9.8028
Nose Configuration	1 pack nose	0.5894

Note: This spreadsheet consists of 3 tabs. Complete "Ballast", "Worksheet", and the tab relevant to your particular glider.



Calculating H-moment (Roll Method)

- 1- Place well-ballasted glider in tank with wings.
- 2- Add a known amount of weight (~300 g) on one wing rail
- 3- Attach a spring scale to the glider on the opposite wing rail
- 4- Measure the weight change shown on the spring scale
- 5- Measure the angle of roll that the glider undergoes due to the addition of weight. For this step you can use an inclinometer (less accurate) or have the glider on and measure compass roll before and after weight addition and measure angle difference.
- 6- Remove the added weight, measure weight, and multiply by 0.912 if using Lead weight or by 0.875 if the weight used is stainless steel. This factor accounts for buoyancy provided by water on material.

Roll Start	0.0000	radians
Roll End	0.0000	radians

Weight on Spring	0.00	grams
Weight added on wing rail	0.00	grams
Angle of Rotation	0.00	degrees
Radius of Hull + Distance to Weight	107	mm

(radius of hull: 200m=107, 1000m=110)

H-distance	#DIV/0!	mm
------------	---------	----

Weight of Pitch Battery	8.5222	kg
Total range of Pitch Battery (+/- in)	1.00	inches
Pitch Range	#DIV/0!	Degrees

Calculating H-moment (Pitch Battery method)

- 1- Put battery position (c_battpos) at about .25, ensure front of glider is not touching bottom of tank- adjust as necessary
- 2- Record m_pitch and m_battpos
- 3- Put battery position at 0
- 4- Record m_pitch and m_battpos

Weight of Pitch Battery	8.5222	kg
Pitch_1	-0.022689	radians
Battery Position_1	0.008487	inches
Pitch_2	-0.13439	radians
Battery Position_2	0.277226	inches

H-Distance	7.55	mm
Total range of Pitch Battery (+/- in)	1.00	inches
Pitch Range	31.92	Degrees

Sign:  Date: 1-28-22



Document #:	4095-GBPSH
Rev:	G
Date:	1/0/1900
ECO #:	0

Glider Ballast Worksheet

Glider Name: Unit 970
Ballasting Technician: DS
Date: 1/21/2022
Glider Displacement (L): 67.8
H-Moment (mm): 7.55

TANK WATER:

Temperature (°C):	19.29
Conductivity (S/m):	4.81
Salinity (psu):	35.75
Density (g/L°C):	1025.5221


TARGET WATER

Temperature (°C):	19.29
Conductivity (S/m):	4.81
Salinity (psu):	35.75
Density (g/L°C):	1025.5221


Pie Weight Locations

Pie weights can be removed or shifted around to indicate exact location. The quantity can also be changed to represent stacked pie weights.


Additional Bay FWD



Science FWD



Science AFT



Wing Rail Weight Locations

Shade in the location of wing rail weights.



Final Weight Configuration As Sent to Customer

Forward	Weight (g)	Payload	Weight (g)	Aft	Weight (g)
Port Bottle	62	Top FWD		Aft Bottle STBD	151
STBD Bottle	62	Bottom FWD	800	Aft Bottle Port	116
		Add Bay Top FWD	800		
		Add Bay Bottom FWD	800		
Desiccant	0.1246	Weight Bar			
		Science Aft	200		
Pond Wings:					
Pinger Channel:					

RBR

Conductivity Calibration Certificate

RBRlegato® C.T.D, Teledyne Webb Slocum, dry bay (1000dbar) s/n: 207969


References: Autosal8400B#66289, MS-315#15506, SSW P164, RC#002

Reference Resistance (ohm)	Reference Conductivity (mS/cm)	Voltage Ratio, V	Measured Conductivity (mS/cm)	Calibration Error (mS/cm)	Coefficients	
open	0.0000	-0.000073	-0.0011	-0.0011	C0:	12.841213E-3
694.042	7.4240	0.038983	7.4235	-0.0006	C1:	190.10136
331.926	15.5233	0.081590	15.5233	-0.0000	(K) C2:	1.001942
150.019	34.3462	0.180613	34.3477	0.0014	X0:	129.42121E-6
100.016	51.5179	0.270944	51.5197	0.0018	X1:	-8.297758E-6
75.023	68.6798	0.361212	68.6798	-0.0001	X2:	0.0
55.520	92.8068	0.468122	92.8054	-0.0014	X3:	0.0
					X4:	0.0
					X5:	14.877353
					X6:	10
Bath	Voltage Ratio	Temperature (ITS-90)	Salinity (PSS-78)	Conductivity (mS/cm)		
T15S35	0.2250136	14.87735	34.9920	42.7882		
T25S35	0.2777701	24.76386	34.9969	52.8204		


Cell Constant @T15S35 = 5.15259 1/cm

$$C_c = \frac{C_0 + C_1 * C_2 * V - X_0 * (T - X_5)}{1 + X_1 * (T - X_5) + X_2 * (P - X_6) + X_3 * (P - X_6)^2 + X_4 * (P - X_6)^3}$$

Calibration error vs. Conductivity



Calibration error vs. Temperature



Calibration Date: 2021-08-18
 Issue Date: 2021-08-18
 File Name: 207969_20210818_1712C.rsk

Operator:


 jwang

Approver:


 kmalorny




Temperature Calibration Certificate

Logger ID: RBRlegato³ Serial No: 207969 Channel No: 2

Reference Temperature, ITS-90	Voltage ratio, V	Measured Temperature, ITS-90	Calibration error	Coefficients	
-4.78985	0.690939	-4.78981	0.00004	C0:	3.521882E-3
0.80423	0.624032	0.80414	-0.00009	C1:	-252.00658E-6
6.98883	0.547163	6.98882	-0.00000	C2:	2.5916398E-6
12.86468	0.474640	12.86478	0.00010	C3:	-75.07101E-9
18.60966	0.407082	18.60968	0.00002		
24.33581	0.345129	24.33572	-0.00009		
30.11677	0.289312	30.11676	-0.00002		
34.99245	0.247885	34.99248	0.00004		

Residuals vs. Temperature



Calibration Date: 2021-08-09
Issue Date: 2021-08-10
Calibration ID: 48215

Operator: 
dluong

Approver: 
jwang



Pressure Calibration Certificate

RBRlegato® C.T.D, Teledyne Webb Slocum, dry bay (1000dbar) s/n: 207969

Instrument rating: 1,000 dbar s/n: N009852

Nominal accuracy: 0.05%FS (0.5 dbar)

Reference instrument: Mensor CPC8000 s/n: 612676


Applied pressure, P_{app} (dbar)	Voltage ratio, V	Measured pressure, P_c (dbar)	Calibration error (dbar)	Coefficients	
10.137	0.017519	10.1442	0.0076	C0:	-31.065626
110.000	0.059695	110.0066	0.0066	C1:	2.365059E3
210.000	0.101878	210.0020	0.0020	C2:	37.59913
310.000	0.144023	310.0075	0.0075	C3:	-30.175407
410.000	0.186126	410.0001	0.0001	X0:	10.1366
510.000	0.228207	510.0144	0.0144	X1:	78.56043E-3
609.999	0.270241	609.9772	-0.0218	X2:	-12.593171E-6
709.998	0.312277	709.9941	-0.0039	X3:	-212.69845E-9
809.997	0.354299	810.0081	0.0111	X4:	-116.62482E-6
909.998	0.396306	910.0085	0.0105	X5:	22.79612
1010.000	0.438306	1009.9976	-0.0024		

$$P_c = X_0 + \frac{P_m - X_0 - X_1(T - X_5) - X_2(T - X_5)^2 - X_3(T - X_5)^3}{1 + X_4(T - X_5)}$$


Head (mm) = 242

$$P_m = C_0 + C_1V + C_2V^2 + C_3V^3$$

Calibration error vs. Pressure (Tcal = 22.8°C)



Calibration error vs. Temperature (Patm = 10.07 dbar)



Calibration Date: 2021-08-16

Issue Date: 2021-08-16

File Name: 207969_20210816_1629P.rsk

Operator:

dluong

Approver:

kmalorny



a xylem brand

CALIBRATION CERTIFICATE

Form No 830, March 2021

Certificate no: 4831_961_00181587
Foil batch no: 1824M

Product: 4831
Calibration date: 14.02.2021

Serial no: 961
Page 1 of 2

Index	Temperature reference(°C)	[O2] Reference(μM)	Temperature raw data(mV)	Phase reading(°)
0	30.229	1.60	-124.913	61.22
1	20.144	1.15	200.347	62.23
2	10.107	0.95	526.513	63.05
3	0.864	0.83	805.607	63.76
4	0.949	21.03	803.180	61.08
5	1.023	42.83	801.100	58.46
6	1.085	63.30	799.333	56.24
7	1.133	110.00	797.940	51.92
8	1.169	151.47	796.940	48.77
9	1.203	217.99	795.973	44.66
10	1.234	323.87	795.080	39.81
11	1.250	436.82	794.627	36.10
12	1.262	540.06	794.293	33.53
13	10.810	16.50	504.147	60.04
14	10.713	34.69	507.260	56.95
15	10.641	51.52	509.507	54.44
16	10.592	86.46	511.073	50.08
17	10.565	122.86	511.940	46.45
18	10.544	172.50	512.620	42.52
19	10.531	262.60	513.007	37.38
20	10.520	341.25	513.360	34.22
21	10.499	430.12	514.040	31.57
22	20.672	13.31	183.040	58.89
23	20.613	27.49	184.973	55.53
24	20.568	41.88	186.453	52.61
25	20.534	67.66	187.540	48.30
26	20.505	95.26	188.500	44.65
27	20.482	138.17	189.260	40.29
28	20.462	204.25	189.900	35.59
29	20.450	273.72	190.280	32.18
30	20.440	344.86	190.607	29.65
31	30.402	10.82	-130.307	57.74
32	30.386	22.45	-129.820	54.13
33	30.380	34.04	-129.600	51.07
34	30.381	56.06	-129.660	46.37
35	30.385	79.35	-129.800	42.54
36	30.392	112.91	-130.000	38.39
37	30.409	167.14	-130.533	33.76
38	30.416	227.18	-130.733	30.31
39	30.422	284.31	-130.933	28.02



Certificate no: 4831_961_00181587
Foil batch no: 1824M

Product: 4831
Calibration date: 14.02.2021

Serial no: 961
Page 2 of 2

Giving these coefficients

Index	0	1	2	3	4	5	6
SVUFoilCoef	2.74988E-03	1.13980E-04	2.55480E-06	1.00392E02	-1.38412E-01	-2.27002E01	2.01418E00
TempCoef	2.62880E01	-3.10956E-02	3.05055E-06	-4.49677E-09	0.00000E00	0.00000E00	



With following settings

Index	0	1	2	3
PhaseCoef	-2.86200E00	1.00000E00	0.00000E00	0.00000E00

Index	0 (Offset)	1 (Slope)
ConcCoef	0.00000E00	1.00000E00

Salinity 0.00

Firmware Version 5.3.1

Date: 14.02.2021

Tor-Ove Kvalvaag
Tor-Ove Kvalvaag, Calibration Engineer



a xylem brand

PRESSURE CERTIFICATE

Form No. 667, Sept 2009

Product: Oxygen Optode 4831

Certificate No: 181492260961

Serial No: 961

Date: 11.02.2021

This is to certify that this product has been pressure tested with the following instrument, and we confirm that no irregularities were found during the test:

Autoklav 800 bar – sn: 0210005

Pressure readings:

Pressure (Bar)	Pressure time (hour)
600	1

Date: 11 Feb 2021

Sign:

Laila A. Skålnes

Laila Skålnes, Production Engineer

Program Version: 5.3.1

Product: Oxygen Optode 4831

Serial No: 961

Visual and Mechanical Checks:

- 1.1 Soldering quality
- 1.2 Visual surface
- 1.3 Galvanic isolation between housing and electronics

Current Drain and Voltages:

2.1	Average current drain at 0.5 Hz sampling (Max.: 33 mA)	23.2	mA
2.2	CANBus Current drain at 0.5 Hz sampling (Max.: 33 mA)		mA
2.3	Current drain in sleep (Max.: 270 μ A)	229	μ A
2.4	CANBus Current drain in sleep (Max.: 180 μ A)		μ A
2.5	DSP IO voltage, J4.18 (3.3 \pm 0.15V)	3.29	V
2.6	DSP Core voltage, J4.17(1.8 \pm 0.05 V)	1.80	V
2.7	Excitation driver voltage, C4 Analog Board (4.3 \pm 0.1 V)	4.34	V

Performance test:

	Channel:	Blue	Red
3.1	Average of Receiver readings (0 \pm 150mV)	-5.2 mV	-2.7 mV
3.2	Standard Deviation of Receiver readings (Max.: 45mV/10mV)	3.52 mV	0.58 mV
3.3	Amplitude measurement with non-fluorescence foil (<60mV/650-1200mV)	8.4 mV	989.8 mV
3.4	CANBus Output test		

Function test from 0 to 40°C:

	Channel:	Blue	Red
4.1	Minimum amplitude measurement (Blue: >550 mV, Red >550 mV)	631.9 mV	785.6 mV
4.2	Maximum amplitude measurement (Blue: <1600 mV, Red <1400 mV)	984.6 mV	1258.6 mV
4.3	Minimum phase measurement (Blue: >32°, Red: >3°)	34.81 °	5.82 °
4.4	Maximum phase measurement (Blue: <45°, Red: <10°)	40.88 °	7.33 °
4.5	Maximum standard deviation of Phase measurement: (< 0.07°)	0.05 °	0.04 °
4.6	Minimum temperature raw data measurement: (<-200 mV)		-454.3 mV
4.7	Maximum temperature raw data measurement: (>450 mV)		722.9 mV

Date: 11 Feb 2021

Sign:

Laila A. Skålnes

Laila Skålnes, Production Engineer

Contents of the shipping box



Vangjorden 2
N-1381 RUD
Norway
Tel: +47 6717 4800
Fax: +47 6713 6770
Inquiry@nortek-as.com
www.nortek.no

Nortek order no:

46317-917

Type of system:

GLIDER 1MHz

Instrument type:

- | | | | | |
|---|----------------------------------|--|---------------------------------------|---|
| <input type="checkbox"/> Aquadopp | <input type="checkbox"/> AWAC | <input type="checkbox"/> Vectrino | <input type="checkbox"/> Signature100 | <input type="checkbox"/> Signature1000 |
| <input type="checkbox"/> Aquadopp profiler | <input type="checkbox"/> VM AWAC | <input type="checkbox"/> Vectrino profiler | <input type="checkbox"/> Signature250 | <input checked="" type="checkbox"/> NortekDVL |
| <input type="checkbox"/> Aquadopp DW 3000/6000m | <input type="checkbox"/> Vector | <input type="checkbox"/> Signature55 | <input type="checkbox"/> Signature500 | <input type="checkbox"/> NLR DVL |

Software version:

NORTEK DISCOVER

Firmware version:

1.4.1056.3055-10/18

Other:

Cable:

☐ 10m length

☒ Other: 2m

Connector:

☒ 8-pin Inline

☐ 12-pin UW

☐ 6-pin Inline

☐ 7-pin Souriau

Other:

Communication:

☐ RS232

☒ Ethernet

☐ RS422

Other:

Options:

☐ Analog Input

☐ Synch

☐ Analog output

Other:

Battery cannister:

☐ Paradopp battery cannister

☐ Single battery aluminium cannister

☐ Double battery aluminium cannister

Battery cables:

☐ 2pin Inline-2pin

☐ 8pin Inline-2pin

☐ 8pin rectangular-2pin

Accessories:

☒ Toolkit

☒ Quick guide

☐ Final test checklist

☐ Seeding material

☒ USB to serial converter RS232

☐ Altronix AL310 USB driver

☐ Recorder kit/ProLog

☐ Battery harness for 2 batteries

Batteries:

Extra set:

☐ Alkaline 50Wh

13.5V

☐

☐ Alkaline 100Wh

13.5V

☐

☐ Alkaline 540Wh

13.5V

☐

☐ Alkaline 540Wh

18V

☐

☐ Alkaline 90Wh

15V (Signature1000)

☐

☐ Alkaline 180Wh

18V (Signature500)

☐

AC/DC Power supply

☐ 15V standard

☐ 48V Signature55

☐ 24V Vectrino

Online

☒ 24V DC/DC & Signature

Plug

☐ EU

☐ UK

☒ US

Other:

2m SERIAL CABLE.

Date:

13.8.2021

Responsible:

Sulphur Swan

Final test checklist AD2CP



Vangskroen 2
N-1353 RUD
Norway
Tel: +47 6717 4550
Fax: +47 6718 6770
inquiry@nortek-gs.com
www.nortek.no

Order number:

46317-917

Name:

Glider

Instrument serial number:

102878

Frequency:

1MHz

Main board:

AD2CP-3302

Firmware versions:

1.4.6056.3055_10/185

Label checked ☒ OK

Dock test ☒ OK

Baudrate 115200 ☒ OK

Comments:

Tilt check

☒ Pitch up

☒ Roll up

☒ Status bit

☒ Pitch down

☒ Roll down

pitch & roll within +/- 0.2 °

Clock

☒ Set clock

Heading

☒ Up

☒ Down

tolerance: +/- 2


Pressure

Psensortemp

☒ OK

tolerance: +/- 0.1 % of

1000 m



Temperature

☒ OK

tolerance: +/- 0.1 °

Beam check

Correct order	Beam Imp	Noise floor	Amplitude in tank	Range
Beam 1 <input checked="" type="checkbox"/> OK	<input type="checkbox"/>	Ω 27 dB	> 80 dB	<input checked="" type="checkbox"/> OK
Beam 2 <input checked="" type="checkbox"/> OK	<input type="checkbox"/>	Ω 29 dB	> 80 dB	<input checked="" type="checkbox"/> OK
Beam 3 <input checked="" type="checkbox"/> OK	<input type="checkbox"/>	Ω 27 dB	> 80 dB	<input checked="" type="checkbox"/> OK
Beam 4 <input checked="" type="checkbox"/> OK	<input type="checkbox"/>	Ω 27 dB	> 80 dB	<input checked="" type="checkbox"/> OK
Beam 5 <input checked="" type="checkbox"/> OK	<input type="checkbox"/>	Ω 27 dB	> 80 dB	<input checked="" type="checkbox"/> OK

Velocity direction

XYZ coordinate system

X ☐ OK

Y ☐ OK

Z ☐ OK

Z2 ☐ OK

ENU coordinate system

E ☐ OK

N ☐ OK

U ☐ OK

U2 ☐ OK

N/A

Head file

☒ Headfile checked

☒ Saved as read only

Serial communication

☐ RS422

☒ RS232

Trigger

☒ TTL

☐ RS485

Recorder erased

☒ OK

Rec size: 16 GB

Ethernet

MAC address: 8C:68:78:00:0C:E6

Static IP address:

Set host name: 102878

DHCP enabled ☒

FTP OK ☒

Licenses

Averaging mode ☒ Wave mode ☐ Vertical velocity ☐ 64GB recorder ☐ Calibration license erased ☒

Burst Five beams ☐ Echo Sounder ☐ Dual frequency low ☐ 128GB recorder ☐ Production license erased ☒

Bottom track ☒ Ice Measurement ☐ Dual frequency high ☐ 256GB recorder ☐ Default configuration set ☒

High Resolution ☐ Altimeter ☐ 16GB recorder ☒

Cable/Harness

Cable ☒ Harness ☒

Communication ☒ Communication ☒

Battery ☐ Battery ☐

Electrical isolation test

50V OK ☒

External sensors

Power down

☒ OK

Date

Day 13 Month 08 Year 2021

Remy Arsenault
Signature



Certificate of Calibrations and Tests

Page 1 of 3

Instrument Information

Customer Reference No.	46317-917
Instrument Type	Glider
Instrument Frequency	1000 kHz
Instrument S/N	102878
Head S/N	D-2878
Interface Board S/N	3302
Interface Board Mfr. S/N	4MO0886950064
Digital Board Mfr. S/N	4MO0870240028
Analog Board Mfr. S/N	4MO0886960030
Sensor Board Mfr. S/N	4MO0789490009
Interface Board Rev.	H-4
Digital Board Rev.	I-3
Analog Board Rev.	G-1
Sensor Board Rev.	I-0

Calibrations and tests performed

Pressure	Passed
Tilt and Compass	Passed

All the tested values are within Nortek AS specifications

August 13, 2021

Date


Reviewed and approved (sign.)



Pressure Report

Page 2 of 3

Details

Instrument Type	Glider
Instrument S/N	102878
Pressure Range	1000 dBar
Date	August 11, 2021
Operator	Faramarz Torkzad
Location	Nortek Factory Norway
Result	Passed

Description

Verification is performed in an automated pressure chamber. Fixed-point measurements are collected to verify the sensor.

Criteria of acceptance is $\pm 0.1\%$ of full scale.

Reference: Paroscientific, Inc. - Digiquartz 9000-10K-101. Accuracy 0.01% of 6895dBar.

Verification Results

Reference (dBar)	Pressure Diff. (dBar)	Pressure Diff. (% of FS)
96.24	0.27	0.03
195.16	0.15	0.02
294.78	0.10	0.01
397.48	0.10	0.01
511.04	0.02	0.00
595.69	-0.01	0.00
707.20	-0.09	-0.01
802.44	-0.08	-0.01
897.53	-0.20	-0.02
1016.19	-0.27	-0.03



Tilt and Compass Report

Page 3 of 3

Details

Instrument Type	Glider
Instrument S/N	102878
Date	August 11, 2021
Operator	Remy Øvereng
Location	Nortek Factory Norway
Result	Passed

Description

Calibration and verification is performed in a two axis automated jig. Continuous and fixed-point measurements are collected to calibrate and verify the sensor.

Criteria of acceptance for tilt sensor is $\pm 0.5^\circ$.

Criteria of acceptance for compass sensor is $\pm 3^\circ$.

Reference: Generic - Digital Protractor Series 950 Pro 3600. Accuracy $\pm 0.05^\circ$.

Tilt Verification Results

Reference (°)	Diff. Up		Diff. Down	
	Pitch (°)	Roll (°)	Pitch (°)	Roll (°)
-30.00	-0.12	0.02	-0.11	-0.13
-15.00	-0.03	0.14	0.06	0.00
0.00	0.05	-0.06	0.11	0.08
15.00	-0.13	0.01	-0.14	-0.14
30.00	0.03	0.11	0.04	0.01

Compass Verification Results

Reference (°)	Heading Diff. Up (°)	Heading Diff. Down (°)
0.00	0.59	0.71
45.00	0.40	0.48
90.00	0.06	0.18
135.00	-0.02	-0.14
180.00	0.25	-0.28
225.00	0.46	-0.16
270.00	0.88	0.23
315.00	0.74	0.71



PRESSURE TRANSDUCER CALIBRATION DATA

Customer

TELEDYNE BENTHOS

Date

9 JUL 21

Model Number

141698-2000A

Serial Number

129995

Diaphragm Materials

TITANIUM

Excitation

5 VDC

Pressure Range

2000 PSIA

Excitation Type

Constant Voltage

Pressure Calibration Data all readings are in mV DC

Date of Pressure Calibration

19 JUN 21

Pressure	Increase	Decrease	Ideal	Linearity (%FS)	Hysteresis (%FS)	STATIC ERROR BAND ± .08% FS BFSL
0 PSIA	.31	.27	.31		.04%	
1000 PSIA	53.24	53.14	53.08	.15%	.09%	
2000 PSIA	105.85		105.85			
SENSITIVITY	105.54					

Thermal Calibration Data all readings are in mV DC

Date of Thermal Calibration

19 JUN 21


	Low Temp.	Ambient	High Temp	Temperature Range	Thermal Balance Shift	Thermal Sensitivity Shift
Temperature	35°F	75°F	75°F			
0 PSIA	.26	.28	.12	35°F to 75°F	.02%FS	-.03%FS
2000 PSIA	105.88	105.87	104.60	75°F to 75°F	-.15%FS	-1.05%FS
Sensitivity	105.62	105.59	104.48	AVERAGE	± .002% FS/°F	± .014% FS/°F

Notes

DATE OF LAST
MEASUREMENT:

23 JUN 21

BALANCE OUTPUT:
.30 mV DC



INPUT RESISTANCE 1499 Ohms
OUTPUT RESISTANCE 741 Ohms

Data Entered and Reviewed By

THARIN THAV

Date Data Entered

1 July 2021



**TELEDYNE
WEBB RESEARCH**
Everywhere you look™

A business unit of Teledyne Instruments, Inc.
49 Edgerton Drive
North Falmouth, MA 02556
P: +1 508.563.1000 F: +1 508.563.6444

CERTIFICATE OF COMPLIANCE

Sales Order No. R123614

This is to certify that the materials & services used for:

Customer Memorial University of N. F.

Purchase Order No. P0165278

conform to the drawings, specifications and conditions called for in the above Customer Purchase Order Number and Teledyne standards.

Country of Origin – Assembled in the United States of America with U.S. & foreign components.

<u>Model No.</u>	<u>REV</u>	<u>QTY</u>	<u>Product Description</u>	<u>Serial Number(s)</u>
<u>GLD-0107-D</u>	<u>1</u>	<u>1</u>	<u>G3S, Memorial University, 1KM RBR</u>	<u>970</u>
<u></u>	<u></u>	<u></u>	<u>CTD, Optode, ASSY 306186 Lithium</u>	<u></u>
<u></u>	<u></u>	<u></u>	<u>Recharge Customer Supplied Crate and</u>	<u></u>
<u></u>	<u></u>	<u></u>	<u>Cart</u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>
<u></u>	<u></u>	<u></u>	<u></u>	<u></u>

Authorized By:

Shawn Green
Name (print)


Signature

01/28/22
Date